

GATEWAY

USER GUIDE

<http://www.gateway-3ds.com/>


3DS firmware 4.1-4.5

Step 1

a) Prepare BLUE Gateway Installer card



b) Copy files from Blue Card (R4i) folder to the Root of a fat 32 formatted Micro SD Card.



Step 2 (repeat on DS mode entry)



a) Run Gateway installer



b) Press A to install



c) Press A to power down or Home to return to main menu.


Remove Blue Gateway cart.

Note : Step 2 must be repeated any time the console enters DS mode.

Step 3



Copy Launcher.dat from GW Release to the root of the SD card from the 3DS .



Step 4 Launching Gateway mode (repeat every power cycle)





Wait for 5 to 8 seconds for system to reboot into GW mode.

GW mode




Step 5

 Preparing Micro SD cards for the Gateway cart.

a) Please download Win32 Disk Imager from the following link
<http://sourceforge.net/projects/win32diskimager/files/latest/download>


b) Start Win32 Disk Imager and select file open button, choose all file types to list .3DS and select your file.



c) Insert Micro SD **larger** than the file to be written into reader/writer.

MAKE SURE TO SELECT THE CORRECT DEVICE in Win32 Disk Imager drop down list.
(Note: The Micro SD needs to be preformatted in order to show up in the device list.)

Select Write, double check correct target device and yes to the pop-up confirm overwrite window.



YAY you're done! :)

Insert Micro SD into Red Gateway Card.

Make sure you are running in Gateway Mode as shown in Step 4.

Insert Gateway and enjoy!

Automatic Save Game Transfer Feature

When swapping games it is important to follow the "Home" --> "Close" sequence in order to enable the Gateway save game transfer from the Gateway Card to the 3DS SD card.

For every new game Gateway will write a file to the 3DS SD card only on game exit via the "home"--> "Close" routine. When the same game is started, the file is transferred back to the Gateway Card in real time.

******* TIPS DO NOT UPDATE 3DS SYSTEM FIRMWARE**

Preventing accidental system update:

It is strongly recommended to enable parental controls in order to prevent an accidental system update.

Gateway will endeavor to provide timely updates to ensure the latest backups can be used.

While our current release is for firmware 4.1-4.5 future updates past 6.2 will most likely close off our convenient Gateway Mode Launcher.

Getting a system lower than 4.1 up to 4.1-4.5 can safely be done by running a 3DS original game released between January 2013 and June 2013. (Please double check the system version update message to ensure nothing above 4.5)

<http://www.gateway-3ds.com/>

Trouble shooting:

Gateway Mode fails to relaunch (hang for longer than 20 sec, black screens or main menu error):

- 1) Make sure 3DS is running system version 4.1 -> 4.5
- 2) Check Launcher.dat is in the root directory of the SD card of the 3DS
- 3) Confirm 3DS can read/write to SD card (Try freshly formatted card, 3DS should pop up message on card insertion)
- 4) Re-Run Blue card Gateway Installer

No banner pops up on red Gateway insertion

- 1) Make sure you are in Gateway mode (Settings -> Other -> Profile -> DS Prof. -> wait for reboot)
- 2) Make sure your backup is the correct region for your console
- 3) Make sure you are binary writing the backup to the micro SD card.

You enter in DS profile settings while trying to launch Gateway Mode:

- 1) Re-Run Blue card Gateway Installer

